



1. Tighten screw until flush with the work-surface.



2. Place stem of cap into drive recess and push in firmly