

SIMLEAD Wood Drawer System **sc-99**






Drawer System Space Requirement


■16mm Drawer Side Thickness



■19mm Drawer Side Thickness




■Push-Open + Soft-Closing Series



W=Internal Cabinet Width
L=Slide Length
X=Height of Slide + Drawer Side
H =Internal Cabinet Height
BH=Drawer Back Height
M=Drawer Side Height


SIMLEAD Wood Drawer System SC-99





SIMLEAD Wood Drawer System EUR©FIT **SC-99**






SIMLEAD Wood Drawer System










Before installation

■ Drawer does not move smoothly - Check the squareness of the drawer box.





■ Push Open Switch



Caution:

1.Make sure two sides (Left & Right) are switched to the same mode.
2.Push Open function will be disabled after switch to Soft Close. Please reserve space for pulling out.

Transport /

Remove the synchronization rod and the connector as shown below.





Troubleshooting



Drawer Size & Hole Positioning

Headquarter

Tel:+886-7-959-9688 | Fax:+886-7-696-7018 KingSlide USA, Inc.

Tel:+1-713-750-9063 | Fax:+1-713-750-9127 E-mail:sales@kingslide.com | WEB: www.kingslide.com